

DO NOT USE FOR FLIGHT



PART III – Normal Procedures

Captain Sim is not affiliated with any entity mentioned or pictured in this document.
All trademarks are the property of their respective owners.

DO NOT USE FOR FLIGHT

ABOUT THIS MANUAL

VERSION: 23 JULY, 2009

WARNING:

THIS MANUAL IS FOR 777 CAPTAIN EXPANSION FOR MS FSX®/FSX-SE®/LOCKHEED MARTIN Prepar3D® ONLY. DO NOT USE FOR FLIGHT. DO NOT USE FOR TRAINING, COMMERCIAL OR INSTITUTIONAL PURPOSES.

The '777 Captain' MANUAL is organized into four Parts:
Each Part is provided as a separate Acrobat® PDF document:

- Part I – User's Manual
- Part II – Aircraft Systems
- **Part III – Normal Procedures** - this document
- Part IV - Flight Management System.

All Parts of the Manual are available free of charge via [Sim Ops](#).

DO NOT USE FOR FLIGHT**CONTENTS**

Page	
4	OPERATING LIMITATIONS
4	<u>GENERAL</u>
4	<u>AIRPLANE GENERAL</u>
4	OPERATIONAL LIMITATIONS
4	NON-AFM OPERATIONAL INFORMATION
4	AIRPLANE WEIGHT RESTRICTIONS
5	<u>AUTO FLIGHT</u>
5	<u>ENGINE</u>
5	<u>ENGINE FUEL SYSTEM</u>
5	<u>REVERSE THRUST</u>
5	<u>FLIGHT CONTROLS</u>
5	<u>NAVIGATION</u>
6	NORMAL PROCEDURES
6	INTRODUCTION
6	GENERAL
6	NORMAL PROCEDURES
8	PREFLIGHT AND POSTFLIGHT AREAS OF RESPONSIBILITY AND PANEL FLOW
9	PILOT FLYING AND PILOT NOT FLYING AREAS OF RESPONSIBILITY
10	AMPLIFIED PROCEDURES
10	EXTERIOR INSPECTION
10	PREFLIGHT PROCEDURE - FIRST OFFICER
15	PREFLIGHT PROCEDURE - CAPTAIN
17	BEFORE START PROCEDURE
20	NORMAL PROCEDURES - AMPLIFIED PROCEDURES
20	ENGINE START PROCEDURE
20	AFTER START PROCEDURE
21	BEFORE TAKEOFF PROCEDURE
21	TAKEOFF PROCEDURE
22	CLIMB PROCEDURE
22	CRUISE PROCEDURE
22	DESCENT PROCEDURE
22	APPROACH PROCEDURE
23	LANDING PROCEDURE
23	GO-AROUND PROCEDURE
24	LANDING ROLL PROCEDURE
24	AFTER LANDING PROCEDURE
25	SHUTDOWN PROCEDURE
25	SECURE PROCEDURE
26	767 CHECKLISTS
26	NORMAL PROCEDURES
27	FLIGHT PATTERNS
28	TAKEOFF
29	ILS APPROACH
30	INSTRUMENT APPROACH USING VNAV
31	INSTRUMENT APPROACH USING V/S
32	CIRCLING
33	VISUAL TRAFFIC PATTERN
34	CUSTOMER SUPPORT

DO NOT USE FOR FLIGHT**OPERATING LIMITATIONS****GENERAL**

This chapter contains Airplane Manual (AM) limitations and Boeing recommended operating limitations. Limitations that are obvious, shown on displays or placards, or incorporated within an operating procedure are not contained in this chapter.

AIRPLANE GENERAL**OPERATIONAL LIMITATIONS**

Runway slope	±2%
Maximum Operating Altitude	43,100 feet pressure altitude
Maximum Takeoff and Landing Altitude	8,400 feet pressure altitude
Maximum Takeoff and Landing Tailwind Component	10 knots

NON-AFM OPERATIONAL INFORMATION**Note**

The following items are not AFM limitations, but are provided for flight crew information.

Turbulent air penetration speed is: 290 KIAS/.78 Mach.

The navigation and display system does not support operations at latitudes greater than 87° North or South.

AIRPLANE WEIGHT RESTRICTIONS**MAXIMUM WEIGHT LIMITATIONS**

Weights	Pounds
Maximum Taxi Weight (MTW)	413,000
Maximum Take Off Weight (MTOW)	412,000
Maximum Landing Weight (MLW)	320,000
Maximum Zero Fuel Weight (MZFW)	295,000

OTHER WEIGHT RESTRICTIONS**Note**

These weights may be further restricted by field length limits, climb limits, tire speed limits, brake energy limits, obstacle clearance, or enroute and landing requirements.

DO NOT USE FOR FLIGHT

AUTO FLIGHT

After takeoff, the autopilot must not be engaged below 200 feet AGL.

Use of aileron trim with the autopilot engaged is prohibited.

Maximum allowable wind speeds when landing weather minima are predicated on autoland operations:

Headwind	25 knots
Crosswind	25 knots
Tailwind	10 knots

ENGINE

Continuous ignition must be on (engine start selector in the CONT position) while operating in severe turbulence.

Note

Continuous ignition is automatically provided in icing conditions when engine anti-ice is on.

Flight crew shall not blank engine vibration display during takeoff.

ENGINE FUEL SYSTEM

The maximum fuel temperature is 49° C (120° F).

The minimum inflight fuel tank temperature is 3°C (5°F) above the freeze point of the fuel being used.

The center tank may contain up to 2000 pounds of fuel with less than full main tanks provided center tank fuel weight plus actual zero fuel weight does not exceed the maximum zero fuel weight, and center of gravity limits are observed.

REVERSE THRUST

Reverse thrust is for ground use only.

Backing the airplane with use of reverse thrust is prohibited.

FLIGHT CONTROLS

The maximum altitude for flap extension is 20,000 ft.

NAVIGATION

Do not operate under IFR or at night into airports north of 73° North or south of 60° South latitude whose navigation aids are referenced to magnetic north.

NORMAL PROCEDURES**INTRODUCTION****GENERAL**

This chapter contains Normal Procedures. It incorporates routine normal procedures and associated flight patterns.

NORMAL PROCEDURES

Normal procedures are used by the trained flight crew to ensure airplane condition is acceptable and that the flight deck is correctly configured for each phase of flight. These procedures assume all systems are operating normally and automated features are fully utilized.

Procedures are performed from recall and follow a panel flow. These procedures are designed to minimize crew workload and are consistent with flight deck technology. If the correct indication is not observed during accomplishment of procedures, verify controls are positioned correctly. If necessary, check the appropriate circuit breaker(s) and test the related system light(s).

Before engine start, lights or indications verify the systems' condition or configuration. Review the EICAS status display before engine start to determine if messages are displayed which may affect dispatch and require maintenance action or compliance with the Minimum Equipment List (MEL).

After engine start, it is not necessary to check status messages as any message having an adverse effect on safe continuation of the flight, and requiring crew attention, will appear as an EICAS alert message (warning, caution, or advisory).

EICAS alert messages are the primary means of alerting the flight crew to non-normal conditions or improper configuration. During engine start and prior to takeoff, any alert message requires accomplishment of the appropriate non-normal procedure. Upon completion of the procedure and prior to takeoff, the Dispatch Deviations Guide (DDG) should be consulted to determine if MEL relief is available.

Exterior lighting, flight deck lighting, and personal comfort items (such as shoulder heaters) are systems assumed to have obvious procedural requirements and are not addressed in this section.

Flight crew duties are organized in accordance with an area of responsibility concept. Each crewmember is assigned a flight deck area where the crewmember initiates actions for required procedures. The panel illustrations in this section describe each crewmember's area of responsibility for pre/post flight and phase-of-flight.

Pre/post flight duties are apportioned between the captain and first officer, while phase-of-flight duties are apportioned between the pilot flying (PF) and pilot not flying (PNF). A normal panel flow is encouraged; however, certain items may be handled in the most logical sequence for existing conditions. Actions outside the crewmember's area of responsibility are initiated at the direction of the captain. General phase-of-flight responsibilities are as follows:

Pilot flying:

- flight path and airspeed control
- airplane configuration
- navigation.

Pilot not flying:

- checklist reading
- communications
- tasks requested by PF
- fuel shutoff and fire switches (with PF concurrence).

Phase-of-flight duties, beginning with the takeoff procedure and ending with the landing roll procedure, are presented in table form in the appropriate procedures section.

The first officer, when flying the airplane, performs the duties listed under pilot flying and the captain performs those duties listed under pilot not flying.

Note: Although the mode control panel is designated as the pilot flying's

DO NOT USE FOR FLIGHT

responsibility, the pilot not flying should operate the controls on the mode control panel at the direction of the pilot flying when the airplane is being flown manually.

DO NOT USE FOR FLIGHT

Autopilot Flight Director System and Flight Management System Monitoring

When the autopilot, flight director, or autothrottle is in use and a mode change is selected or is scheduled to occur, the annunciation must be verified on the flight mode annunciation display. Airplane course, vertical path, and speed must always be monitored.

Similarly, when a thrust reference mode change is selected or is scheduled to occur, the annunciation must be verified on the EICAS display.

In LNAV and VNAV, all airplane course, vertical path, thrust, and speed changes must be verified.


CDU Operation

On the ground, the control display unit (CDU) manipulations are normally performed by the first officer and verified by the captain.

In flight, CDU entries are accomplished by the pilot not flying and verified by the pilot flying prior to execution. CDU manipulations should be accomplished prior to high workload periods such as departure, arrival, or holding. During high workload periods, using autopilot modes such as heading select, flight level change, and the altitude and speed intervention features, along with the map switches, may be more efficient than entering complex route modifications into the CDU.

DO NOT USE FOR FLIGHT

PREFLIGHT AND POSTFLIGHT AREAS OF RESPONSIBILITY AND PANEL FLOW



Audio Control Panel (ACP) and trim location may vary


■ Captain

□ First Officer

LEGEND: Shaded area defines Captain's area of responsibility. Unshaded area is First Officer's responsibility.

DO NOT USE FOR FLIGHT

PILOT FLYING AND PILOT NOT FLYING AREAS OF RESPONSIBILITY



Weather Radar (WX) Audio Control Panel (ACP) and trim location may vary

■ PF area of Responsibility

■ PNF area of Responsibility

□ Unshaded areas are the responsibility of the pilot seated on the respective side.

AMPLIFIED PROCEDURES

EXTERIOR INSPECTION

Prior to each flight, a flight crewmember or the maintenance crew must verify the airplane is acceptable for flight.

Check:

- Flight control surfaces unobstructed and all surfaces clear of ice, snow, or frost.
- Door and access panels (not in use) properly secured.
- Ports and vents unobstructed.
- Airplane free of damage and fluid leakage.
- Wheel chocks in place, ground locking pins removed, and nose gear steering lever in normal position.
- Tire condition.
- Gear struts not fully compressed.

PREFLIGHT PROCEDURE - FIRST OFFICER

This procedure assumes the supplementary power up procedure has been accomplished and electrical power is established.

The following procedures are accomplished in their entirety on each originating trip or crew change, or following maintenance action.

Normally this procedure is accomplished by the First Officer. However, it does not preclude the captain from completing the procedure if time and conditions dictate.

- Maintenance documentsCheck
- FLIGHT DECK ACCESS SYSTEM switch.....NORM
- RESERVE BRAKES & STRG RESET/DISABLE guard.....Closed
Verify ISLN light extinguished.
- Circuit breakersCheck
- Emergency equipment.....Check
- IRS mode selectorsOFF, then NAV
Verify ALIGN lights illuminated.
For all flights, a full alignment is recommended.
- YAW DAMPER switchesON
INOP lights remain illuminated until IRS alignment is complete.
- EEC switches.....NORM
- HYDRAULIC panelSet
- LEFT and RIGHT ENGINE PRIMARY pump switches - ON
Left and right engine pump PRESS lights remain illuminated until the respective engine is started.
ELECTRIC PRIMARY pump switches - OFF
DEMAND pump selectors - OFF
- HF radioSet
- BATTERY/STANDBY CONTROL panel.....Set
BATTERY switch - ON
Verify DISCH light extinguished.
STANDBY POWER selector - AUTO

DO NOT USE FOR FLIGHT

Verify standby power bus OFF light extinguished.

ELECTRICAL panelSet
BUS TIE switches - AUTO
Verify AC BUS OFF and utility bus OFF lights extinguished. APU GENERATOR switch - ON

GENERATOR CONTROL switches - ON
OFF and DRIVE lights remain illuminated until respective engine is started.

APU selector.....START, then ON
Position the APU selector back to the ON position. Do not allow the APU selector to spring back to the ON position.

Lighting panelSet
GLARESHIELD panel light controls - As desired
AISLE STAND panel light controls - As desired
LIGHT OVERRIDE switch - As desired
RUNWAY TURNOFF light switches - OFF

EMERGENCY LIGHTS switchARMED
Verify UNARMED light extinguished.

PASSENGER OXYGEN ON light.....Extinguished

CAUTION:

Switch activation causes deployment of passenger oxygen masks.

RAM AIR TURBINE UNLKD light.....Extinguished

WARNING:

Switch activation may cause deployment of the ram air turbine.

ENGINE CONTROL panelSet
Engine ignition selector - 1 or 2
Engine start selectors - AUTO

FUEL JETTISON panelSet
NOZZLE switches - OFF
Selector-OFF

FUEL panel.....Set
CROSSFEED switches - OFF
Verify VALVE lights extinguished.

FUEL PUMP switches - OFF
Left and right pump PRESS lights are illuminated.
Left forward pump PRESS light is extinguished if the APU is running.
Both center pump PRESS lights are extinguished.

ANTI-ICE panel.....Set
WING anti-ice switch - OFF
ENGINE anti-ice switches - OFF

WIPER selectorOFF

Lighting panelSet
POSITION light switch - As required
RED and WHITE ANTI-COLLISION light switches - OFF
WING light switch - OFF
LANDING light switches - OFF

WINDOW HEAT switches.....ON
Verify INOP lights extinguished.

HF radioSet

PASSENGER SIGNS panelSet

DO NOT USE FOR FLIGHT

NO SMOKING selector - AUTO or ON
SEATBELTS selector - AUTO or ON

CABIN ALTITUDE CONTROL panelSet
AUTO RATE control - Index
LANDING ALTITUDE selector - Destination airport elevation
MODE SELECTOR - AUTO 1 or AUTO 2

EQUIPMENT COOLING mode selectorAUTO

Lighting panelSet
CIRCUIT BREAKER panel light control - As desired
OVERHEAD PANEL light control - As desired
DOME LIGHT control - As desired
LOGO light switch - As desired
INDICATOR LIGHT selector - As desired

BLEED AIR panelSet
ENGINE bleed air switches - ON
Verify OFF lights illuminated.
APU bleed air switch - ON
Verify VALVE light extinguished.
LEFT, CENTER and RIGHT ISOLATION switches - ON
Verify VALVE lights extinguished.

Air conditioning panelSet
PACK CONTROL selectors - AUTO
Verify PACK OFF lights extinguished.
FLIGHT DECK temperature control - AUTO
Set as desired.
Verify INOP lights extinguished.
TRIM AIR switch - ON
RECIRCULATION FAN switches - ON
Verify INOP lights extinguished.
CABIN temperature controls - AUTO
Set as desired.
Verify INOP lights extinguished.

CARGO HEAT switchesON

Right VOR/DME switchAUTO

Right FLIGHT DIRECTOR switchON

EICAS displayCheck

Secondary ENGINE DISPLAY switch - Push
Indications - Normal. Verify:

- primary and secondary engine indications display existing conditions
- no exceedance values are displayed
- oil quantity adequate for flight.

STATUS DISPLAY switch - Push

STATUS display - Verify:

- hydraulic quantities do not display RF

If any status message is displayed, refer to the Minimum Equipment List and Dispatch Deviation Guide to determine if dispatch relief is available.

COMPUTER selector - AUTO

Right CDUSet

If MENU page displayed:
FMC line select key - Push
If IDENT page not displayed:

DO NOT USE FOR FLIGHT

INITREF key-Push
INDEX line select key - Push
IDENT line select key - Push
IDENT page - Check
 Verify active date current.
 Verify Fuel Flow Factor is +1.7 or greater for PW4000 series engines.
POS INIT line select key - Push
 Verify time correct.
Inertial position - Enter
 Enter inertial position using the most accurate latitude and longitude.
ROUTE line select key - Push
 Select company route or load route manually.
ACTIVATE line select key - Push
EXEC key-Push
DEPARR key-Push Select runway and SID.
ROUTE line select key - Push
 Verify SID and route are correct.
EXEC key-Push

Right EFIS control panelSet
 Decision height selector - As desired
 TERRAIN switch - As desired
 HSI RANGE selector - As desired
 HSI TRAFFIC switch - As desired
 HSI mode selector - MAP
 HSI CENTER switch - As desired
 WEATHER RADAR switch - Off
 MAP switches - As desired

WEATHER RADAR panelSet
 Set panel - As desired

Left VHF communications panelSet

Center VHF communications panelSet

Engine fire panelSet

ENG BTL 1 DISCH and ENG BTL 2 DISCH lights - Extinguished

Engine fire switches - In
 Verify LEFT and RIGHT fire warning lights extinguished.

ADF panelSet
 Set panel - As desired

Transponder panelSet

ILS panelSet
 Set panel - As desired

CARGO FIRE panelSet
 CARGO FIRE ARM switches - Off
 Verify FWD and AFT fire warning lights extinguished.
 CARGO FIRE BTL DISCH light - Extinguished

APU fire panelSet
 APU BTL DISCH light - Extinguished
 APU fire switch - In
 Verify APU fire warning light extinguished.

Right VHP communications panelSet

First officer's audio control panelSet
 Set panel - As desired

DO NOT USE FOR FLIGHT

Window 2 right.....Locked

Verify the lock lever is in the locked (forward) position and the WINDOW NOT CLOSED decal is not in view.

First officer's HEATERSSet
FOOT and SHOULDER switches - As desired

First Officer's Lighting panelSet
PANEL light control - As desired
CHART light control - As desired
FLOOD light control - As desired
MAP light control - As desired

Right INSTRUMENT SOURCE SELECT panelSet
FLIGHT DIRECTOR selector - R
NAVIGATION SOURCE selector - FMC-R
ALTERNATE SOURCE switches - Off

Right flight instrumentsSet

Note:

IRS alignment must be complete before AUTOLAND STATUS, VSI, ADI, HSI, and RDMI checks.

ALTIMETER - Correct
Set the local altimeter setting.
Verify instrument indications are correct.
Verify no flag displayed.

VERTICAL SPEED INDICATOR - Correct
Verify instrument indications are correct.
Verify no flag displayed.

Clock - Correct
DATE switch - GMT

ADI - Correct
Flight mode annunciations - Verify:
• autothrottle mode is blank
• roll mode is TO
• pitch mode is TO
• AFDS status is F/D.
Flight instrument indications are correct.
Verify no flags displayed.

HSI - Correct
Verify magnetic track correct.
Verify present heading correct.
Verify map mode displayed.
Verify no flags displayed.
Route - Displayed, correct

Airspeed indicator - Correct
Verify instrument indications are correct.
Verify no flag displayed.

RDMI - Correct
VOR/ADF switches - As desired.
Verify instrument indications are correct.
Verify no inappropriate flag displayed.

AUTOLAND STATUS annunciatorCheck
Verify blank indications.

HEADING REFERENCE switch.....NORM or TRUE

DO NOT USE FOR FLIGHT

- FLAP position indication and FLAP leverAgree
- ALTERNATE FLAPSSet
 - ALTERNATE FLAPS selector - NORM
 - ALTERNATE FLAPS switches - OFF
- Landing gear panelSet
 - Landing gear lever - DN
 - ALTERNATE GEAR EXTEND switch - OFF (guarded position)
- GROUND PROXIMITY FLAP OVERRIDE switch.....Off
- GROUND PROXIMITY GEAR OVERRIDE switch.....Off
- GROUND PROXIMITY TERRAIN OVERRIDE switch.....Off
- Right seat.....Adjust
 - Position seat for optimum eye reference.

WARNING:

Do not place objects between the seat and the aisle stand. Injury can occur when the seat is adjusted forward.

- Rudder PedalsAdjust
 - Adjust to permit full rudder pedal and brake application.
- Right seat belt and shoulder harness.....Adjust
 - Accomplish PREFLIGHT checklist on captain's command.

PREFLIGHT PROCEDURE - CAPTAIN

Normally, this procedure is accomplished by the captain. However, it does not preclude the first officer from completing the procedure if time and conditions dictate.

- Left VOR/DME switch.....AUTO
- Mode control panel.....Set
 - Left FLIGHT DIRECTOR switch - ON
 - AUTOTHROTTLE ARM switch - ARM
 - BANK LIMIT selector - As desired
 - Autopilot DISENGAGE bar - UP
- LeftCDU.....Set
 - If MENU page displayed:
 - FMC line select key - Push
 - If IDENT page not displayed:
 - INITREF key-Push
 - INDEX line select key - Push
 - IDENT line select key - Push
 - IDENT page - Check
 - Verify active date current.
 - Verify Fuel Flow Factor is +1.7 or greater for PW4000 series engines.
 - POS INIT line select key - Push
 - Verify present position and time correct.
 - ROUTE line select key - Push
 - Verify:
 - flight number correct
 - route correct.
- Left EFIS control panelSet
 - Decision height selector - As desired
 - TERRAIN switch - As desired
 - HSI RANGE selector - As desired
 - HSI TRAFFIC switch - As desired

DO NOT USE FOR FLIGHT

HSI mode selector - MAP
HSI CENTER switch - As desired
WEATHER RADAR switch - Off
MAP switches - As desired

SPEEDBRAKE lever.....DOWN

ALTERNATE STABILIZER TRIM switches.....Neutral

Reverse thrust leversDown

DO NOT USE FOR FLIGHT

WARNING:

Movement of the reverse thrust lever could result in operation of the engine thrust reverser.

- Thrust levers.....Closed
- Flap leverSet
Position lever to agree with flap position.
- Parking brake.....Set
Verify PARK BRAKE light illuminated.
- STABILIZER TRIM cutout switchesNORM (guarded position)
- FUEL CONTROL switches.....CUT OFF
- Captain's audio control panel.....Set
Set panel - As desired
- Window 2 left.....Locked
Verify the lock lever is in the locked (forward) position and the WINDOW NOT CLOSED decal is not in view.
- Captain's HEATERSSet
FOOT and SHOULDER switches - As desired
- Captain's Lighting panel.....Set
PANEL light control - As desired
CHART light control - As desired
FLOOD light control - As desired
MAP light control - As desired
- Left INSTRUMENT SOURCE SELECT panelSet
FLIGHT DIRECTOR selector - L
NAVIGATION SOURCE selector - FMC-L
ALTERNATE SOURCE switches - Off
- Left flight instrumentsSet
Note:
IRS alignment must be complete before AUTOLAND STATUS, VSI, ADI, HSI, and RDMI checks.
- Airspeed indicator - Correct
Verify instrument indications are correct.
Verify no flag displayed.
- RDMI - Correct
VOR/ADF switches - As desired.
Verify instrument indications are correct.
Verify no inappropriate flag displayed.
- ADI - Correct
Flight mode annunciations - Verify:
 - ..autothrottle mode is blank
 - ..roll mode is TO
 - ..pitch mode is TO
 - ..AFDS status is F/D.
 Flight instrument indications are correct.
Verify no flags displayed.
- HSI - Correct
Verify magnetic track correct.
Verify present heading correct.
Verify map mode displayed.
Verify no flags displayed.
Route - Displayed, correct
- ALTIMETER - Correct
Set the local altimeter setting.
Verify instrument indications are correct.
Verify no flag displayed.

DO NOT USE FOR FLIGHT

- VERTICAL SPEED INDICATOR - Correct
 - Verify instrument indications are correct.
 - Verify no flag displayed.
- Clock - Correct
 - DATE switch - GMT

AUTOLAND STATUS annunciatorCheck
Verify blank indications.

RESERVE BRAKES AND STEERING switch.....OFF
Verify VALVE light extinguished.

Standby instrumentsCheck

- Standby ADI - Check
 - ILS selector-OFF
 - Verify no flags displayed.
- Airspeed indicator - Check
 - Verify instrument indications are correct.
- Altimeter - Set
 - Set local altimeter setting.
 - Verify instrument indications are correct.

Standby engine indicator selectorAUTO

AUTO BRAKES selectorOFF

Left seatAdjust
Position seat for optimum eye reference.

WARNING:

Do not place objects between the seat and the aisle stand. Injury can occur when the seat is adjusted forward.

Rudder pedalsAdjust
Adjust to permit full rudder pedal and brake application.

Left seat belt and shoulder harness.....Adjust

BEFORE START PROCEDURE

This procedure is accomplished after papers are on board and flight crew is ready for push back and/or engine start.

Takeoff thrust referenceSet C, F/O
Verify correct thrust reference mode displayed.

CDUSet C,F/O

- INITREF key-Push
 - Verify fuel quantities agree:
 - upload fuel quantity
 - fuel quantity indicator
 - CDU.
 - Enter:
 - zero fuel weight
 - reserve fuel
 - cruise altitude
 - cost index.
 - Check:
 - Step size

- TAKEOFF line select key - Push
 - Enter:
 - takeoff flap setting.
 - CG
 - position shift value (if required).
 - wind (if required).

DO NOT USE FOR FLIGHT

- slope (if required).
- Check:
- thrust line.
 - acceleration height.

Verify PRE-FLT COMPLETE displayed
 CDU display-Set
 Usually one pilot on LEGS page and the other on CLB page.

Note:

If required for noise abatement reasons, enter a speed restriction, on the CLIMB page, of VREF 30 + 80 to 3,000 feet above field elevation.

MCPSet..... C
 IAS/MACH selector - Rotate
 Set V2 speed in the IAS/MACH window.
 Initial heading - Set
 Initial altitude - Set

Airspeed bugsSet C, F/O
 Set bugs at VI, VR, VREF 30 + 40, and VREF 30 + 80.

Start clearance.....Obtain C, F/O
 Obtain clearance to pressurize hydraulic systems and start engines.

HYDRAULIC panelSet..... F/O

Note:

Pressurize right system first to prevent fluid transfer between systems.

Right ELECTRIC DEMAND pump selector - AUTO
 Verify PRESS lights extinguished.
 C1 and C2 ELECTRIC PRIMARY pump switches - ON
 Verify C1 PRESS light extinguished.
 Center AIR DEMAND pump selector - AUTO
 Verify PRESS lights extinguished.
 Left ELECTRIC DEMAND pump selector - AUTO
 Verify PRESS lights extinguished.

Note:

C2 PRESS light will not be extinguished due to load shedding. Indication will be normal after engine start.

FUEL panel.....Set..... F/O
 LEFT and RIGHT FUEL PUMP switches - ON
 Verify PRESS lights extinguished.
 If center tank contains fuel:
 CENTER FUEL PUMP switches - ON

Note:

Both PRESS lights will not be extinguished due to load shedding. Indications will be normal after engine start.

RED ANTI-COLLISION light switch.....ON F/O
 PACK CONTROL selectors.....OFF F/O

Trim..... Units, zero, zero C, F/O
 Stabilizer trim - _____ UNITS
 Set for takeoff.
 Check in greenband.
 Aileron trim - ZERO
 Rudder trim-ZERO

Flight controlsCheck C
 Displace control wheel and control column to full travel in both directions and verify:

- freedom of movement

DO NOT USE FOR FLIGHT

- controls return to center
- proper flight control movement on EICAS status display.

Hold the nose wheel steering tiller during rudder check to prevent undesired nose wheel movement.
Displace rudder pedals to full travel in both directions and verify:

- freedom of movement
- rudder pedals return to center
- proper flight control movement on EICAS status display.

Secondary ENGINE DISPLAY switch.....PUSH..... F/O

Call for "BEFORE START CHECKLIST."C

Accomplish BEFORE START checklist.F/O

DO NOT USE FOR FLIGHT

NORMAL PROCEDURES - AMPLIFIED PROCEDURES

ENGINE START PROCEDURE

Captain	First Officer
Announce start sequence.	
Normal start sequence is right then left	
Call "START _____ENGINE."	Position _____START selector to GROUND.
Observe oil pressure increase	
Position _____FUEL CONTROL switch to RUN when:	
<ul style="list-style-type: none"> at maximum motoring and a minimum of 15% N2 	
Observe initial EGT rise and EGT within limits. Abort start if EGT fails to rise within 20 seconds of selecting RUN or if EGT rising rapidly or approaching limit. Abort start if N1 fails to increase at EGT rise. Abort start if N2 fails to reach stabilized idle within 120 seconds of selecting RUN. Do not advance thrust beyond that required for taxi until 50°C oil temperature.	

Repeat procedure to start remaining engine.

AFTER START PROCEDURE

- APU selector.....OFF F/O
 - ENGINE ANTI-ICE switchesAs required F/O
 - LEFT and RIGHT ISOLATION switches.....OFF F/O
 - PACK CONTROL selectors.....AUTO..... F/O
 - RECALLCheck C, F/O
- If any message displayed refer to Minimum Equipment List and Dispatch Deviation Guide or airline equivalent to determine if dispatch relief is available.
- AUTO BRAKES selectorRTO..... C
 - Ground equipmentClear C, F/O
 - Call for "AFTER START CHECKLIST.".....C
 - Accomplish AFTER START checklist.F/O

DO NOT USE FOR FLIGHT

BEFORE TAKEOFF PROCEDURE

- Obtain taxi clearanceF/O
- Brief taxi clearanceC
- Parking brake.....Release..... C
- Call for "FLAPS __" as required for takeoffC
- Position flap lever to takeoff setting.F/O
- Takeoff briefingAccomplish..... C
- Flight attendantsNotify F/O
- Call for "BEFORE TAKEOFF CHECKLIST."C
- Accomplish BEFORE TAKEOFF checklist.....F/O

TAKEOFF PROCEDURE

Pilot Flying	Pilot Not Flying
Release brakes. Align airplane with runway.	Position LEFT and RIGHT WING LANDING and WHITE ANTI-COLLISION light switches ON. Position transponder mode selector to TA/RA.
Advance thrust levers to approximately 1.10 EPR. Push THR switch.	
Verify correct takeoff thrust set.	Monitor engine instruments throughout takeoff. Adjust takeoff thrust prior to 80 knots, if required.
Note: After takeoff thrust is set, the captain's hand must be on the thrust levers until VI.	
Monitor airspeed.	Monitor airspeed indications and call out any abnormalities.
Verify 80 knots.	Call "80 KNOTS."
Verify V1 speed. Rotate at VR. Establish a positive rate of climb.	Call "V1" At VR call "ROTATE." Monitor airspeed and vertical speed.
Call for "GEAR UP" when positive rate of climb established.	Verify positive rate of climb then position landing gear lever UP.
Call for "LNAV" when climb stabilized.	Push L NAV switch.
Call for "VNAV" at flap retraction altitude. Push A/P ENGAGE COMMAND switch.	Push VNAV switch.
Call for "FLAPS ____" according to flap retraction schedule.	Position flap lever as directed.
Verify climb thrust set.	

DO NOT USE FOR FLIGHT

Call for "AFTER TAKEOFF CHECKLIST."	Position landing gear lever OFF after GEAR and DOORS lights extinguish. Accomplish AFTER TAKEOFF checklist.
-------------------------------------	--

CLIMB PROCEDURE

Pilot Flying	Pilot Not Flying
	Above 10,000 feet, position LANDING light switches OFF.
At transition altitude, set altimeters to 29.92 in Hg (1013 mb).	

CRUISE PROCEDURE

Pilot Flying	Pilot Not Flying
	When CTR L and CTR R FUEL PUMP messages are displayed, push CENTER FUEL PUMP switches OFF.

DESCENT PROCEDURE

Pilot Flying	Pilot Not Flying
	Prior to top of descent, modify active route as required for arrival and approach.
	Verify pressurization set to landing altitude.
Set DH as required for approach.	Set DH, ADF, and ILS as required for approach.
Review all alert messages.	Recall and review all alert messages.
Set airspeed reference bugs to VREF 30, VREF 30 + 40 and VREF 30 + 80.	Set airspeed reference bugs to VREF 30, VREF 30 + 40 and VREF 30 + 80.
Set AUTO BRAKES selector to desired brake setting.	
When cleared to descend, set clearance limit altitude on MCP.	

APPROACH PROCEDURE

Pilot Flying	Pilot Not Flying
At transition level, set altimeters.	
Verify correct arrival and approach procedures selected.	
Accomplish approach briefing.	
	At 10,000 feet, position LEFT and RIGHT WING LANDING light switches ON.

DO NOT USE FOR FLIGHT

Call for "APPROACH CHECKLIST."	Accomplish APPROACH checklist.
--------------------------------	--------------------------------

DO NOT USE FOR FLIGHT

LANDING PROCEDURE

Pilot Flying	Pilot Not Flying
	Notify flight attendants.
Call for "FLAPS ___" according to flap extension schedule.	Position flap lever as directed.
When on localizer intercept heading, verify ILS tuned and identified and localizer and glideslope pointers displayed, arm APP mode.	
At glideslope alive, call for: "GEAR DOWN" "FLAPS 20."	Position landing gear lever DN. Position flap lever to 20.
Position speedbrake lever to ARM.	
At glideslope capture, call for "FLAPS ___" as required for landing.	Position flap lever as commanded.
Set missed approach altitude on MCP.	
At final approach fix/OM, verify crossing altitude.	
Call for "LANDING CHECKLIST."	Accomplish LANDING checklist.
Monitor approach progress. Verify Autoland status at 500 feet radio altitude.	

GO-AROUND PROCEDURE

Pilot Flying	Pilot Not Flying
Push go-around switch. Call for "FLAPS 20."	Position flap lever to 20.
Verify rotation to go-around attitude and thrust increase.	
	Verify thrust adequate for go-around; adjust if necessary.
After positive rate of climb established, call for "GEAR UP."	Verify positive rate of climb then position landing gear lever UP.
Above 400 feet radio altitude, select LNAV or HDG SEL.	
At flap retraction altitude, set speed to VREF 30 + 80. Call for "CLIMB THRUST."	Push CLIMB thrust reference mode select switch.
Call for "FLAPS ___" according to flap retraction schedule.	Position flap lever as directed.
After flap retraction, select FLCH or VNAV as required.	
Verify missed approach route being tracked and missed approach altitude captured.	

DO NOT USE FOR FLIGHT

Call for "AFTER TAKEOFF CHECKLIST."	Position landing gear lever OFF after GEAR and DOORS lights extinguish. Accomplish AFTER TAKEOFF checklist.
-------------------------------------	--

LANDING ROLL PROCEDURE

Pilot Flying	Pilot Not Flying
Monitor rollout progress and proper auto brakes operation.	
Verify thrust levers closed and speedbrake lever up. Without delay, raise reverse thrust levers to the interlocks, hold light pressure until release, and then apply reverse thrust as required.	Verify speedbrake lever UP and call "SPEEDBRAKES UP." If speedbrake lever not UP, call "SPEEDBRAKES NOT UP."
By 60 knots, initiate movement of reverse thrust levers to reach reverse idle detent prior to taxi speed. Position levers full down (forward thrust) when engines have decelerated to reverse idle.	Call "60 KNOTS."
Prior to taxi speed, disarm the auto brakes and continue manual braking as required.	
Disconnect autopilot prior to runway turnoff.	

WARNING

After reverse thrust is initiated, a full stop landing must be made.

AFTER LANDING PROCEDURE

Accomplished when clear of the active runway.

- APU selector.....START, then ON..... F/O
Position the APU selector back to the ON position. Do not allow the APU selector to spring back to the ON position.
- Exterior lights.....Set..... F/O
Position WHITE ANTI-COLLISION light switch OFF and LANDING/TAXI light switches as required.
- Speedbrake lever.....DOWN C
- Weather radarOff C,F/O
- AUTO BRAKES selectorOFF F/O
- Flaps.....UP..... F/O
- Transponder.....Off F/O

DO NOT USE FOR FLIGHT

SHUTDOWN PROCEDURE

- Parking brakeSet..... C
Verify PARK BRAKE light illuminated.
- Electrical powerEstablish F/O
If APU power is required:
Check APU RUN light is illuminated.
If external power is desired:
EXTERNAL POWER AVAIL light - Illuminated
EXTERNAL POWER switch - Push
- ENGINE ANTI-ICE switchesOFF F/O
- FUEL CONTROL switches.....CUT OFF C
Verify ENG VALVE and SPAR VALVE lights extinguished.
- Parking brakeRelease..... C
When wheel chocks in place, release the parking brake.
- SEATBELTS selectorOFF F/O
- HYDRAULIC panelSet..... F/O

Note:

Depressurize right system last to prevent fluid transfer between systems.

- Left ELECTRIC DEMAND pump selector - OFF
- C1 and C2 ELECTRIC PRIMARY pump switches - OFF
- Center AIR DEMAND pump selector - OFF
- Right ELECTRIC DEMAND pump selector - OFF

- FUEL PUMP switches.....OFF F/O
- RED ANTI-COLLISION light switch.....OFF F/O
- LEFT and RIGHT ISOLATION switches.....ON F/O
- FLIGHT DIRECTOR switchesOFF C, F/O
- Status messagesCheck F/O
- APU selector.....Set..... F/O
If APU power is no longer required:
APU selector-OFF
- Call for "SHUTDOWN CHECKLIST."C
- Accomplish SHUTDOWN checklist.....F/O

SECURE PROCEDURE

- IRS mode selectorsOFF F/O
- EMERGENCY LIGHTS switchOFF F/O
- WINDOW HEAT switches.....OFF F/O
- CARGO HEAT switches.....OFF F/O
- PACK CONTROL selectors.....OFF F/O
- Call for "SECURE CHECKLIST."C

DO NOT USE FOR FLIGHT

Accomplish SECURE checklist.F/O

767 CHECKLISTS

NORMAL PROCEDURES

PREFLIGHT		
1	OXYGEN	TESTED, 100%
3	FLIGHT INSTRUMENTS	HEADING ____, ALTIMETER __
4	PARKING BRAKES	SET
5	FUEL CONTROL SWITCHES	CUTOFF

BEFORE START		
1	FLIGHT DECK DOOR	CLOSED AND LOCKED
2	PASSENGER SIGNS	_____
3	WINDOWS	LOCKED
4	MCP	V2 ____, HDG ____, ALT __
5	TAKEOFF SPEEDS	V1 ____, VR ____, V2 __
6	CDU PREFLIGHT	COMPLETED
7	TRIM	_____ UNITS, ZERO, ZERO
8	TAXI AND TAKEOFF BRIEFING	COMPLETED
9	RED ANTI COLLISION LIGHT	ON

BEFORE TAXI		
1	ANTI-ICE	_____
2	L and R ISOLATION SWITCHES	OFF
3	RECALL	CHECKED
4	AUTOBRAKE	RTO
5	GROUND EQUIPMENT	CLEAR

BEFORE TAKEOFF		
1	FLAPS	_____

AFTER TAKEOFF		
1	LANDING GEAR	UP and OFF
2	FLAPS	UP

DESCENT		
1	PRESSURIZATION	LDG ALT
2	RECALL	CHECKED
3	AUTOBRAKE	_____
4	LANDING DATA	VREF ____, MINIMUMS __
5	APPROACH BRIEFING	COMPLETED

APPROACH		
1	ALTIMETERS	SET

LANDING		
----------------	--	--

DO NOT USE FOR FLIGHT

1	SPEEDBRAKE	ARMED
2	LANDING GEAR	DOWN
3	FLAPS	=====

SHUTDOWN		
1	HYDRAULIC PANEL	SET
2	FUEL PUMPS	OFF
3	FLAPS	UP
4	PARKING BRAKE	DOWN
5	FUEL CONTROL SWITCHES	CUTOFF
6	WEATHER RADAR	OFF

SECURE		
1	IRSs	OFF
2	EMERGENCY LIGHTS SWITCH	OFF
3	WINDOW HEAT	OFF
4	PACK SWITCHES	OFF


FLIGHT PATTERNS

DO NOT USE FOR FLIGHT


Takeoff

Flap Retraction Schedule

Select next flap position when within 20 knots of the Maneuvering speed for that Position and accelerating



DO NOT USE FOR FLIGHT



DO NOT USE FOR FLIGHT

Instrument Approach Using VNAV

Approaching intercept heading

- Flaps 5

Intercept Heading

- Arm LNAV or appropriate roll mode

Descend to DA(H) or MDA(H)

- Monitor VNAV path
- Landing checklist

Inbound (2NM)

- Gear down
- Flap 20 (landing flaps for 1 engine)
- Arm speedbrake
- Set DA(H) or MDA(H)
- Select VNAV
- Speed intervention
- Landing flaps (2 engine)

At DA(H) or MDA(H)

- Intercept landing profile and disengage autopilot and disconnect autothrottle

On RADAR vectors

- HDG SEL
- Appropriate pitch mode


Enroute to fix

- LNAV or appropriate roll mode
- VNAV or appropriate pitch mode


Missed approach

- Push GA switch
- Flap 20 (flap 5 for 1 eng)
- Go-around attitude
- Go-around thrust
- Positive rate of climb, gear up
- Above 400 feet select roll mode
- At flap retraction altitude, set speed for desired flap setting
- Select CLB thrust (2 engine)
- Retract flaps on schedule
- After flap retraction, select FLCH or VNAV as required
- Select CON thrust (1 engine)
- Verify tracking route and altitude capture
- After Takeoff checklist

DO NOT USE FOR FLIGHT



DO NOT USE FOR FLIGHT



DO NOT USE FOR FLIGHT

CUSTOMER CARE

SIM OPS

We encourage you to visit the one-stop resource for the 737 Captain flightsim operations: [the Sim Ops](#)

TECHNICAL SUPPORT

If you have trouble with this product, please use our Ticket based support system and an extensive Knowledge Base at: <https://www.captainsim.com/support>

FORUM

You are invited to join [Captain Sim forum](#)

SOCIAL NETWORKS

Please follow us at:

[Twitter](#)

[Facebook](#)

[Google+](#)

[Instagram](#)

VIDEO CHANNEL

For Captain Sim videos please subscribe to our YouTube [channel](#).